



Treatment of Amoxicillin Formulation Effluent by Ozone Technology

*Mariana Cardoso Barros Ribeiro, André Luís de Castro Peixoto
Grupo de Química Tecnológica, Instituto Federal de São Paulo
(IFSP)*

Session 14
25th, September

Introduction




Fig. 1. Amoxicillin structure

((2*S*,5*R*,6*R*)-6-[(2*R*)-2-amino-2-(4-hydroxyphenyl)acetyl]amino]-3,3-dimethyl-7-oxo-4-thia-1-azabicyclo[3.2.0]heptane-2-carboxylic acid)


With chemical formula $\text{C}_{16}\text{H}_{19}\text{N}_3\text{O}_5\text{S}$

It is an antibiotic that belongs to the beta-lactams group and it is often used for bacterial infection treatments

World Health Data Platform / GHO / Indicator Metadata Registry List

Essential Medicines List includes paediatric Amoxicillin syrup

Introduction



Journal of Environmental Management

Volume 261, 1 May 2020, 110236



Review

Removal of caffeine, nicotine and amoxicillin from (waste)waters by various adsorbents. A review

Ioannis Anastopoulos ^a  , Ioannis Pashalidis ^a, Alexios G. Orfanos ^b, Ioannis D. Manariotis ^b, Tetiana Tatarchuk ^{c, h}, Lotfi Sellaoui ^d, Adrián Bonilla-Petriciolet ^e, Alok Mittal ^f, Avelino Núñez-Delgado ^g


Fig. 2. Number of publications on EC.

Objectives

- ❖ **Evaluate the potential application of ozone-based technologies in the removal of amoxicillin (AMX).**
- ❖ Evaluate the effects of the operational factors UV dose, pH, O_3 dose on AMX degradation and mineralization.
- ❖ Determine the reaction kinetics of AMX degradation using ozone-based technologies (O_3 and O_3/UV).
- ❖ Study mechanisms of AMX degradation.
- ❖ Evaluate the influence of 1-propanol and 2-propanol (possible $\bullet OH$ scavenger).



Materials and Methods



- ❖ pH = 9.0; 11.0; and 13.0 ± 0.5
- ❖ Temperature = 20.0 ± 0.5 °C
- ❖ Volumetric flow-rate: 0.5 and 1.0 L min⁻¹
- ❖ Ozone mass-rate: 8.13; 15.00; and 25 mg min⁻¹
- ❖ Low-pressure mercury vapor lamps

Fig. 3. Reaction system diagram.

Materials and Methods




Fig. 4. NCS method mechanism.



$\lambda = 395 \text{ nm}$

Spectrophotometer
Thermo Scientific
Model Genesys 10S UV-Vis

Fig. 5. Spectrophotometer.



Pale-Yellow Collor

Fig. 6. AMX determination.

Results and Discussion




Fig. 7. Normalized AMX concentration abatement kinetics for ozonation of pharmaceutical formulation effluent at pH=13 (a), pH=9 (b), and pH=11 (c).

Results and Discussion




Fig. 8. Normalized AMX concentration abatement kinetics for ozonation of pharmaceutical formulation effluent at pH=9: (a) O_3 at 8.13 mg min^{-1} + UV; (b) O_3 at 15 mg min^{-1} ; and (c) O_3 at 15 mg min^{-1} + UV.

Results and Discussion




Fig. 9. Normalized AMX concentration abatement kinetics for ozonation of pharmaceutical formulation effluent at pH=11: (a) O_3 at 8.13 mg min^{-1} + UV; (b) O_3 at 15 mg min^{-1} + UV; and (c) O_3 at 15 mg min^{-1} .

Results and Discussion




Fig. 10. Normalized AMX concentration abatement kinetics for ozonation of pharmaceutical formulation effluent at pH=13: (a) O_3 at 15 mg min^{-1} ; (b) O_3 at 15 mg min^{-1} + UV; and (c) O_3 at 25 mg min^{-1} + UV.

Results and Discussion




Fig. 11. Normalized AMX concentration abatement kinetics for ozonation of pharmaceutical formulation effluent at pH=13. (a) blank experiment with O_2 injection at 0.5 L min^{-1} ; (b) ozonation process; (c) ozonation process with addition of 2-propanol 0.1 mol L^{-1} ; (d) ozonation process with addition of 1-propanol 0.1 mol L^{-1} .

Conclusions

- ❖ Expiry AMX pharmaceutical effluent was successfully degraded by ozone technology in high pH value.
- ❖ The basic pH medium provided higher AMX solubility, which facilitates mass transfer in a direct/indirect ozone reaction.
- ❖ The ozonation semi-batch process was effective for one hour in all experimental conditions, producing recalcitrant transformation products to the oxidative process.
- ❖ UV light in hydroxyl radicals production is marginal. On the other hand, the ozone dose is the most important parameter so far.

Acknowledgments

Grants #2018/05698-0 and #2019/09991-6





REISZ, E. et al. Reaction of 1-propanol with Ozone in Aqueous Media. International Journal of Molecular Sciences, v. 20, p.4165, 2019.

References

SALEH, G.A.. Two selective spectrophotometric methods for the determination of amoxicillin and cefadroxil. The Analyst, v. 121, n. 5, p.641-645, 1996. Royal Society of Chemistry (RSC).



REMTECH EXPO

21-25 SEPTEMBER 2020

digital edition



THANKS FOR THE ATTENTION,

Prof. Dr. André Luís de Castro Peixoto

Federal Institute of Education, Science and Technology
of São Paulo (IFSP)

+55 19 2146-6700

alcpeixoto@ifsp.edu.br

RemTech Expo Digital Edition 2020 (21-25 September)

www.remtechexpo.com